

Installing O-ring in Water Trap on the Omnidirectional Inlet

Model 854040



Quick Start Guide

This guide will help you quickly install the O-ring (2501646) to the Omnidirectional Inlet (854040).

Installing O-ring

To maintain a tight seal on the water trap jar it is recommended that you install the enclosed O-ring in the water trap jar of the omnidirectional inlet.

1. Unscrew the jar from its housing.
2. Inset the O-ring in the jar cover pressing it against the flat surface above the threads.
3. Retighten the jar into its housing.



TSI and the TSI logo are registered trademarks of TSI Incorporated in the United States and may be protected under other country's trademark registrations.



Knowledge Beyond Measure.

TSI Incorporated – Visit our website www.tsi.com for more information.

USA	Tel: +1 800 680 1220	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8219 7688
France	Tel: +33 1 41 19 21 99	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		

