



Knowledge Beyond Measure.

High-Concentration Nanoparticle Emission Tester

Model 3795-HC



Accurate high-concentration solid particle counting in real-world emissions

Building on the proven, regulatory-compliant Nanoparticle Emission Tester (NPET 3795), the High-Concentration NPET is designed to measure total solid particle number concentrations directly from the tailpipe — whether in the field or during in-use testing.

The instrument supports a wide range of emission sources, including internal combustion engines, gasoline- and diesel-powered vehicles, and biomass power plants. Its robust, user-friendly design makes it ideal for use by researchers, regulatory inspectors, and maintenance personnel.

Equipped with a built-in catalytic stripper that removes volatile particles, the High-Concentration NPET enables accurate measurement of solid particle emissions only. Based on the same unique design principles as certification-grade instruments, it delivers laboratory-quality particle counting in real-world environments — and is capable of handling emission levels beyond certification limits, such as those upstream of after-treatment systems, upstream and downstream of Diesel or Gasoline Particle Filters, cold start emissions or biomass combustion emissions.

Features and Benefits

- Direct measurement of particle number concentration using proven Condensation Particle Counter (CPC) technology
- Sampling probe with integrated dilution to measure concentration up to 100,000,000 particles/cm³
- Selectable measurement modes:
 - Real-time data logging for research
 - User-defined protocols for reporting test cycle results

Applications

- In-use diesel machinery compliance certification
- Exhaust after treatment inspection and maintenance programs
- Diesel Particulate Filter (DPF) retrofit programs
- Gasoline Particle Filter (GPF) characterization
- Fleet emissions profiling
- DPF/GPF regeneration studies
- Cold start emission measurements
- Combustion emissions research (biomass, wood burning)



Specifications

High-Concentration Nanoparticle Emission Tester

Model 3795-HC

Differences Between the NPET Models

	3795	3795-HC
Application	Standard tailpipe measurements or certification according to Swiss Regulation for non-road mobile machinery SR 941.242	High concentrations such as upstream of DPF/GPF, cold start or biomass burning
Concentration Range	1,000 to 5×10^6 particles/cm ³	2,000 to 1×10^8 particles/cm ³

Specifications

Particle Size Range	<50% at 23 nm >50% at 41 nm Solid particles from 23 nm to 1 µm
Concentration Accuracy	± 10%
Response Time	2.5 +/- 0.5 seconds
Sampling Flow	0.7 L/min (nominal)
Working Fluid	99.5%+ reagent-grade isopropyl alcohol; one charge lasts up to 4 hours
Catalytic Stripper	Removes >99% of volatile particles (equivalent 30 nm Count Median Diameter (CMD), Polydisperse C ₄₀ H ₈₂)
Environmental Operating Conditions	-10 °C to 40 °C 75 kPa to 106 kPa
Power Requirement	100 to 240 VAC, 50/60 Hz, 100 W nominal, 200 W peak
Communications	Ethernet, 8-wire RJ-45 jack, 10/100 BASE-T, TCP/IP
Dimensions (H x W x D)	10.2" x 13" x 22.4" (26 cm x 33 cm x 57 cm)
Weight	13.1 kg (28.9 lbs.)

Optional Accessories

3795-TAB	10.5" Windows® tablet with Ethernet dongle and drop resistant case
3795100	Hose and probe assembly for 3795
3795-HC PROBE	Hose and probe assembly for 3795-HC
803120	Pre-soaked alcohol wicks (50 ea.)
801624	Replacement wick assembly to load wicks into NPET
8016	30 mL isopropyl alcohol bottles (16)



Knowledge Beyond Measure.

TSI Incorporated - Visit our website www.tsi.com for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8219 7688
France	Tel: +33 1 41 19 21 99	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		

Specifications are subject to change without notice.

TSI and the TSI logo are registered trademarks of TSI Incorporated in the United States and may be protected under other country's trademark registrations.