



# Detection Management Software



# Installing Detection Management Software

1. Open the flashdrive and plug it into an available USB port on your computer.
2. Right-click on the Windows  button located in the lower left of your computer.
3. Select Open Windows Explorer.
4. Select the DMS logo drive in Windows Explorer. The following example displays DMS in the "D" drive. *Note: your computer drive may display differently such as "E".*



DMS Software drive example

5. Navigate to Setup or Setup.exe file. Double-click on the file to install the DMS software.

Quest is a trademark, and TSI and the TSI logo are registered trademarks of TSI Incorporated.



**TSI Incorporated** - Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**North America and Asia Pacific  
Telephone:**

+1 800-680-1220 (USA)

+1 651-490-2860 (Outside USA)

**Fax:** +1 651-490-3824

**E-mail:** [technical.services@tsi.com](mailto:technical.services@tsi.com)

**Europe, Middle East, and Africa  
Telephone:** +49 241-52303-0

**Fax:** +49 241 52303-49

**E-mail:** [tsigmbh@tsi.com](mailto:tsigmbh@tsi.com)