

# MSP TURBO™ LIQUID FLOW CONTROLLER MODEL 2950



Designed specifically for leading edge microelectronic applications, this highly accurate, high-speed liquid flow controller pairs with MSP Turbo™ Vaporizers to provide unmatched liquid source vapor delivery performance, versatility, and longevity.

<b>Model Number:</b>	2950
<b>Turndown Ratio <sup>[2]</sup>:</b>	30:1
<b>Max Viscosity (cp) <sup>[3]</sup>:</b>	10
<b>Accuracy % F.S. <sup>[4]</sup>:</b>	±1.0
<b>Repeatability % F.S. <sup>[4]</sup>:</b>	±0.4
<b>Linearity % F.S. <sup>[4]</sup>:</b>	±0.6
<b>Response time (s) <sup>[5]</sup>:</b>	< 0.3 to ±1% S.P.
<b>Environmental Temperature (°C):</b>	15-45; 0-80% RH
<b>Liquid Temperature (°C) <sup>[6]</sup>:</b>	15-35, 100% F.S. 35-40, <80% F.S.
<b>Temperature Sensitivity (% F.S.) <sup>[7]</sup>:</b>	±0.05/°C
<b>Max Pressure Drop (kPa/psig) <sup>[8]</sup>:</b>	90/13
<b>Max Operating Pressure (kpa/psig) <sup>[2]</sup>:</b>	360/52
<b>Leak Integrity (Pa m<sup>3</sup>/s, He):</b>	≤ 1×10 <sup>-10</sup>
<b>Power:</b>	+10-30VDC;
<b>Typical</b>	1.0W (w/o EtherCAT) 1.5W (w/ EtherCAT)
<b>Max.</b>	15W
<b>Wetted Materials:</b>	316SS, Nickel, Kalrez, BNI-5
<b>Fittings (Inlet &amp; Exit):</b>	
<b>Inlet</b>	1/8" VCR male
<b>Exit</b>	1/8" VCR male
<b>Interface:</b>	
<b>EtherCAT <sup>[9]</sup></b>	2xRJ45
<b>RS485</b>	9-pin D connector (male)
<b>Analog</b>	9-pin D connector (male)
<b>Software communication via RS485</b>	
<b>3 Output Control Signals:</b>	
	1 Fixed, 1-130V (for Piezo Control)
	2 Configurable
	3 Options: 0-5V, 0-10V, 4-20mA, 1-5V, 2-10V, 0-20mA

## 1 Analog Input:

- 1 Fixed, 1-130V (for Piezo Control)
- 2 Configurable
- 3 Options: 0-5V, 0-10V, 4-20mA, 1-5V, 2-10V, 0-20mA

## Nominal Max Flow (g/min) <sup>[1]</sup>:

Model Number	TEOS Full Scale (g/min)	TEMAZr Full Scale (g/min)	H2O Full Scale (g/min)
2950-002	0.2	N/A	0.14
2950-01	1	0.19	0.73
2950-05	5	0.95	3.6
2950-10	10	1.9	7.3
2950-20	20	3.8	14
2950-30	30	5.7	21

## Other Liquids

The full scale (F.S.) of the 2950 LFC is a function of liquid viscosity ( $\mu_{\text{liquid}(cP)}$ ). To estimate the full scale (F.S.) of each model for your liquid, use the equation below:

If $\mu_{\text{liquid}(cP)} \geq 0.65$	If $\mu_{\text{liquid}(cP)} > 0.65$
$F.S._{\text{Other Liquid}} = F.S._{\text{TEOS}} * \frac{0.65cP}{\mu_{\text{liquid}(cP)}}$	$F.S._{\text{Other Liquid}} = F.S._{\text{TEOS}} * \frac{\mu_{\text{liquid}(cP)}}{0.65cP}$

## Factory Calibration:

TEOS used for factory calibration. For use with other liquids a factory calibration adjustment or field calibration with reference flow meter can be performed using 2950 Configuration Software. Factory calibration for other liquids may be possible. Visit [www.tsi.com/contact](http://www.tsi.com/contact) to request more information.

[1] Nominal max flow determined using TEOS as reference liquid at 23±2°C. Flow rate range is a function of specified liquid.

[2] Determined using TEOS as reference liquid at 23±2°C.

[3] Higher viscosities will result in lower max flow ranges. Consult MSP for more information on use at higher viscosities.

[4] Accuracy, repeatability, linearity and reproducibility tested to SEMI E56-0317 using TEOS at 23±2°C.


[5] Response time determined using TEOS as reference liquid at 23±2°C, when paired with MSP "PE" Turbo-Vaporizer™, full scale flow, optimized PID, 45psi line pressure. Specification applies to all models except 2950-002, which has a response time 2-3 times slower due to the extremely low flow rate.

[6] If the liquid temperature goes above 35°C, the full scale is reduced to 80% of nominal.


[7] For every 1°C away from 23°C, accuracy can be degraded ±0.1%.

[8] Pressure drop in device - not including downstream valves, 23 ± 2°C.

[9] ETG.5003.2020 S (R) V1.1.0 compatible.



# MSP TURBO™ LIQUID FLOW CONTROLLER MODEL 2950



All specifications are subject to change without notification.

Turbo Vaporizer and Turbo Liquid Flow Controller are trademarks.  
 MSP, the MSP logo and TSI are registered trademarks of TSI Incorporated.



**MSP** - Visit our website [www.tsi.com/msp](http://www.tsi.com/msp) for more information.

5910 Rice Creek Parkway, Suite 300  
 Shoreview, Minnesota  
 55126, U.S.A.  
**Tel:** 651.287.8100