

QUICK START GUIDE

Detection Management Software
(from CD)




Installing Detection Management Software (from CD)

NOTE: DO NOT connect any TSI | Quest™ instruments until after installation.

1. Unpack the CD and insert it into the CD drive on your computer.
Note: If AutoRun is enabled on your system, setup will begin automatically and you can skip to Step 4.
2. Open Windows® File Explorer®  and select the "DMS Software" drive in the folder tree (the drive label may vary).



DMS Software
drive example

3. In the root folder of the drive, double-click on the setup (.exe) file to start the installation.
4. Follow the installation wizard instructions.
5. After installation is complete, double-click the DMS shortcut  on the desktop to start DMS.
6. Enter the license key from the package or media label into the Licensing dialog and click **Apply License**.
7. Complete the Localization and voluntary Registration tabs to start DMS.

Quest is a trademark, and TSI and the TSI logo are registered trademarks of TSI Incorporated.



TSI Incorporated - Visit our website www.tsi.com for more information.

North America and Asia Pacific

Telephone: +1 800-680-1220 (USA)
+1 651-490-2860 (Outside USA)

Fax: +1 651-490-3824
E-mail: technical.services@tsi.com

Europe, Middle East, and Africa

Telephone: +49 241-52303-0

Fax: +49 241 52303-49
E-mail: tsigmbh@tsi.com

P/N 6012661 Rev A

©2018 TSI Incorporated

