

ACCUBALANCE® AIR CAPTURE HOOD MODEL 8371


TSI's AccuBalance® Air Capture Hoods measure air volume flowing through registers, diffusers and grilles. Weighing just seven and a half pounds, these air capture hoods are easy to carry, lift and use. Simply hold the AccuBalance up to a diffuser or grille and read direct supply or exhaust airflow on the large digital display.

Features and Benefits

- + Variable time constant modes minimize display variations when measuring fluctuating flows
- + K factor function enables flexibility for measuring a variety of diffusers
- + Variety of hood sizes lets you take readings from most diffusers, registers or grilles
- + Back-lit display is easy to read in poor lighting conditions



UNDERSTANDING, ACCELERATED



SPECIFICATIONS

ACCUBALANCE® AIR CAPTURE HOOD MODEL 8371

Flow Range

30 to 2,000 cfm (15 to 1,000 l/s, 50 to 3,500 m³/hr)

Accuracy

±5% reading and ±5 cfm (±2.4 l/s, ±8.5 m³/hr)

Operating Temperature

32 to 140°F (0 to 60°C)

Weight

7.5 lbs (3.4 kg)[†]

Power

4 C-size batteries (4 alkaline batteries provided)

Battery Life

40 hours continuous use

Carrying Case

26 in. × 26 in. × 7 in. (660 mm × 660 mm × 180 mm)

Hood Sizes Available

Standard	24 in. × 24 in. (610 mm × 610 mm)
Optional	24 in. × 48 in. (610 mm × 1,220 mm)
	12 in. × 48 in. (305 mm × 1,220 mm)
	12 in. × 60 in. (305 mm × 1,525 mm)
	36 in. × 36 in. (915 mm × 915 mm)

Model 8930 Printer Specifications

Printing Method	Thermal serial head system
Printing Speed	Approximately 0.8 lines/sec
External Dimensions	5.3 in. × 5.1 in. × 2.5 in. (135 mm × 130 mm × 64 mm)
Printer Interface	8 bit serial RS-232-C, 1200 baud

	8371
Density correction	+
K-factor	+
Variable time constant	+
Field calibration adjustment	+
Printer output	+
Back-lit display	+
Certificate of Calibration	+

[†]Using 24 in. × 24 in. (610 mm × 610 mm) hood

Specifications are subject to change without notice.

AccuBalance, TSI and the TSI logo are registered trademarks of TSI Incorporated.



UNDERSTANDING, ACCELERATED

TSI Incorporated - Visit our website www.tsi.com for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 4 91 11 87 64	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		