

# MITA MASK ADAPTER KIT MODEL 8125-07

---

INSTRUCTION GUIDE



APPLICABLE MASK MODELS:  
SCOTT AV-2000 & AV-3000 MASKS



## Included Accessories

<p><b>40/74 mm Mask Filter Plug</b> (Qty 1) (for 40 mm threaded (female) adapters)</p> <ul style="list-style-type: none"><li>➤ Installed on mask during <b>Protection Factor</b> test</li></ul>	
<p><b>Mask Filter Plug</b> (Qty 2) (for ¼-turn adapters)</p> <ul style="list-style-type: none"><li>➤ Installed on mask during <b>Protection Factor</b> test</li></ul>	
<p><b>Mask Filter Plug</b> (Qty 1) (for 40mm threaded (male) adapters)</p> <ul style="list-style-type: none"><li>➤ Installed on mask during <b>Protection Factor</b> test</li></ul>	

## Components Installed on Masks



**Example of Scott AV-2000 and AV-3000**

**From left to right; Example of the 1/4-turn, 40mm threaded (male) and 40mm threaded (female) Scott adapters**

The Model 8125-07 MITA Mask Adapter Kit includes all parts necessary for making connections to a variety of Scott filter/cartridge adapters, and is compatible with all Scott AV-2000 and AV-3000 masks which have either a 1/4-turn, 40 mm threaded (male) or 40 mm threaded (female) adapter.



UNDERSTANDING, ACCELERATED

**TSI Incorporated** – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**USA**      **Tel:** +1 800 874 2811  
**UK**        **Tel:** +44 149 4 459200  
**France**   **Tel:** +33 4 91 11 87 64  
**Germany** **Tel:** +49 241 523030

**India**        **Tel:** +91 80 67877200  
**China**       **Tel:** +86 10 8219 7688  
**Singapore** **Tel:** +65 6595 6388