

MITA MASK ADAPTER KIT MODEL 8125-02

INSTRUCTIONS GUIDE



APPLICABLE MASK MODELS:
M50 AND C50



Included Accessories

<p>Drink Tube (DT) Valve Adapter</p> <ul style="list-style-type: none">➤ Installed on mask during DT Flow test	
<p>Mask Filter Plug (Qty. 2)</p> <ul style="list-style-type: none">➤ Installed on mask during Protection Factor test	
<p>Exhalation Valve (EV) Adapter (for M50 and C50 masks)</p> <ul style="list-style-type: none">➤ Connect to Mask Exhalation Valve during EV Leak test	
<p>EV Self Check Zero Fixture</p> <ul style="list-style-type: none">➤ Connect to EV Adapter, during the EV Leak Zero Test option of the Self Checks procedure	

Components Installed on Masks



Example of M50 and C50 with DT Valve Adapter



Example of M50 and C50 with Mask Filter Plug



Example of M50 and C50 with EV Adapter



Example of M50 and C50 with all adapters



UNDERSTANDING, ACCELERATED

TSI Incorporated – Visit our website www.tsi.com for more information.

USA Tel: +1 800 874 2811
UK Tel: +44 149 4 459200
France Tel: +33 4 91 11 87 64
Germany Tel: +49 241 523030

India Tel: +91 80 67877200
China Tel: +86 10 8219 7688
Singapore Tel: +65 6595 6388